

This guide will show you how to setup your Speedtouch 536 Broadband Setup Guide so that you can connect to Saco Technology.

Step 1

Step 1 of 6: Open your Internet browser (e.g. Internet Explorer).

Step 2 of 6: Clear the address bar and type the address <http://10.0.0.138> to connect to the modem configuration page.



Step 3 of 6: Click on the **Internet** option in the Broadband Connection section.



Step 4 of 6: Click the **Disconnect** button. This button will then change to Connect.



Step 5 of 6: Enter your **Username** and **Password**. Remember to enter **@sacotech.com.au** at the end of the username.



Step 6 of 6: Click the **Connect** button. (This button will then change to Disconnect).

