



How to Connect a Linksys SPA 942 VoIP Phone

Step 1.


You must first determine what IP address it received. To do this, on the phone dial pad, press the "envelope" button and then press the button under the LCD screen word "save".

Step 2.

Go to any browser equipped computer on your network and enter the address: `http://<IP ADDRESS>/`
(where <IP ADDRESS> is replaced by the address that was given to you in STEP 1).

Step 3.

Click on the "Admin Login" button near the top right side of the screen, then click on the "Ext 1" tab.



Step 4.

You need to modify only a few parameters from the factory default. They are listed here:

- SIP Port:** 5066
- Proxy:** did.sacotech.com.au
- Register Expires:** 3600
- User ID:** This is your Saco Technology SIP Number
- Password:** Enter your password
- Preferred Codec:** G729a

General	
Line Enable:	yes
NAT Settings	
NAT Mapping Enable:	no
NAT Keep Alive Enable:	no
SIP Settings	
SIP Port:	5066
SIP Debug Option:	none
Call Feature Settings	
Message Waiting:	no
Default Ring:	1
Proxy and Registration	
Proxy:	
Register:	yes
Make Call Without Reg:	no
Register Expires:	3600
Ans Call Without Reg:	no
Subscriber Information	
Display Name:	
User ID:	
Password:	*****
Use Auth ID:	no
Auth ID:	
Audio Configuration	
Preferred Codec:	G729a
Use Pref Codec Only:	no
Silence Supp Enable:	no
DTMF Tx Method:	Auto

After these steps your VoIP phone should now be able to connect to the Saco Technology VoIP Server. In some cases you may need to restart your phone. If you find after following the above steps you still can't connect please contact Saco Technology support.